

Operation Manual
1 Year Replacement Warranty

MSS-002

CAUTION: Read this operation manual before using this tool.



0200

SPECIFICATIONS - MODEL NO. MSS-002

Max capacity:200kgMax roller height:200mm

Weight:

Dimensions fully assembled: max extension - 1730 x 460 x 830mm min extension - 1050 x 460 x 830mm


15kg

Features: Quick and easy to assemble Adjustable support rollers

Folding legs

Saw mounting accessories included

Folds flat for easy storage



- 1. Adjustable support roller
- 2. Extension bar
- 3. Saw mounting brackets
- 4. Saw mounting bracket knobs
- 5. Foldable legs

- 6. Leg locking bar
- 7. Leg locking knob
- 8. Extension bar locking knob
- 9. Support roller adjusting knob

TABLE OF CONTENTS

SPECIFICATIONS - MODEL NO. MSS-002	Page 1
TABLE OF CONTENTS	Page 2
INTRODUCTION	Page 3
SAFETY INSTRUCTIONS	Page 3
ASSEMBLY	Page 4
MAINTENANCE	Page 5
CONTENTS	Page 5
WARRANTY	Page 6

INTRODUCTION

Congratulations on purchasing an Ozito Mitre Saw Stand. We aim to provide quality products at an affordable price. We hope you will enjoy using this product for many years.

The Ozito Mitre Saw Stand MSS-002 is designed to for the mounting of mitre saws. It is intended for DIY use only.

GENERAL

- 1. Keep work areas clean. Cluttered work areas can cause accidents.
- 2. Consider work area environment. Keep the work area well lit.
- Keep children away. Do not allow children, visitors or animals to come near the work area
- **4. Do not overreach.** Keep proper footing and balance at all times.
- **5. Stay alert.** Watch what you are doing. Use common sense. Do not operate a saw mounted to the stand when you are tired.
- **6. Users.** This appliance is not intended for use by young children or infirmed persons without supervision. Young children should be supervised to ensure that they do not play with this appliance.

SAFETY INSTRUCTIONS FOR MITRE SAW STANDS

- Always ensure the mitre saw base is properly secured to the stand prior to operation.
- Always ensure the stand legs have been locked into place prior to operation.
- Take care when moving the stand especially when a mitre saw is mounted.
- Do not use the stand for any other purpose than what it is intended for.
- Do not use the stand as a stepping stool or ladder.

ASSEMBLY

Unfolding the legs

Remove the stand from the packaging. Turn the body of the stand upside down so you can see the folded legs.

Extend all four legs and secure with 4 leg locking knobs and washers supplied. Lock the legs in position with the leg locking bar.

When all four legs have been extended and secured in place, turn the stand the correct way up. Ensure all the legs are properly secured.

Adjustable Support Rollers

Fit the support roller (1) through the extension bar and secure in place by tightening roller adjusting knobs (9) which are on the very ends of the stand. The support rollers can be adjusted up or down using the securing knobs.

Extension Bars

The extension bars (2) can be adjusted as required. Loosen the two locking knobs (8) on the side of the stand then extend or retract the extension bars as required.

Mitre Saw Mounting Brackets

The two mounting brackets have adjusting knobs (4) attached. To attach the brackets to the stand, loosen the knobs, fit the bracket over the top of the stand and then tighten the clamps to secure the brackets to the stand.

Fitting a Mitre Saw to the Stand

Loosen the saw mounting brackets. The brackets have slots going down the centre of them. Position one coach bolt into each end of the bracket slots with the bolt head in the slot to fit a total of 4 coach bolts. Fit the mitre saw over the top of these bolts allowing the threaded ends of the bolts to extend through the mitre saw mounting holes. Fix a flat washer, spring washer then nut over the top of each bolt to secure the base of the mitre saw to the stand. Once the saw has been successfully fitted to the mounting brackets, tighten the mounting bracket knob to fully secure the saw to the stand. During operation and before starting a new job, ensure that all bolts and nuts are tightened correctly.

MAINTENANCE

Wipe away dirt and dust from the stand on a regular basis.

Note: Ozito Industries will not be responsible for any damage or injuries caused by the repair of the tool by an unauthorised person or by mishandling of the tool.

CONTENTS

1 x Stand MSS-002

2 x Saw mounting brackets

4 x 40mm coach bolts

4 x flat washers

4 x spring washers

2 x bracket locking knobs

4 x extension bar locking knobs

2 x roller adjusting knobs

4 x leg locking knobs & flat washers

1 x Instruction Manual

OZITO INDUSTRIES PTY LTD

AUSTRALIA (Head Office)

1 - 23 Letcon Drive, Bangholme, Victoria, Australia 3175

Telephone: 1800 069 486
Facsimile: +61 3 9238 5588
Website: www.ozito.com.au
Email: enquiries@ozito.com.au

WARRANTY

THIS WARRANTY FORM AND CONFIRMED BUNNINGS REGISTER RECEIPT SHOULD BE **RETAINED BY THE CUSTOMER** AT ALL TIMES

The warranty is only made available by returning the product to your nearest Bunnings Warehouse with a **confirmed Bunnings register receipt.**

YOUR WARRANTY FORM SHOULD BE RETAINED BY YOU AT ALL TIMES.

SHOULD YOU HAVE ANY QUESTIONS PRIOR TO RETURNING YOUR PRODUCT FOR WARRANTY OR REPAIR PLEASE TELEPHONE OUR CUSTOMER SERVICE HELPLINE:

Australia 1800 069 486 New Zealand 0508 069 486

TO ENSURE A SPEEDY RESPONSE PLEASE HAVE THE MODEL NUMBER AND DATE OF PURCHASE AVAILABLE. AN OZITO CUSTOMER SERVICE REPRESENTATIVE WILL TAKE YOUR CALL AND ANSWER ANY QUESTIONS YOU MAY HAVE RELATING TO THE WARRANTY POLICY OR PROCEDURE.

PURCHASED FROM:_		
DATE PURCHASED:		

1 YEAR REPLACEMENT WARRANTY

Your Ozito tool is guaranteed for a period of **12 months from the original date of purchase** and is intended for DIY (Do it yourself) use only.

WARNING

The following actions will result in the warranty being void.

- Professional, Industrial or high frequency use.
- If the tool has been operated on a supply voltage other than that specified on the tool.
- If the tool shows signs of damage or defects caused by or resulting from abuse, accidents or alterations.
- If the tool is disassembled or tampered with in any way.

Note: Warranty excludes consumable parts such as rollers, extension bars, legs and accessories.